

TZ-AVL05_New User Guide

Automatic Vehicle Location



I. Welcome to use this car product

- **We keep the final explanation right on this User Guide.**
- **Please don't unfold or maintain it, for fear damaging it, if you don't operate it according to the user's manual, it may damage the product or cause hurt to you, our company would not take responsibility for the loss in this situation.**
- **Our tracking devices may not be used to violate the privacy rights of others, or in violation of local, county, state or federal statutes, and our company will not be responsible for inappropriate use of these products.**
- **AVL is a device that uses the Global Positioning System to determine the precise location of a vehicle, moving house, trailer or other asset which AVL is installed on and to record the position of the AVL at regular intervals. With Sirf Star IV GPS systems, it records not only position, but also velocity, Date time, direction, status of digital output ports, etc.**
- **The main purpose of using AVL is not only to locate the vehicles, but also to obtain information about the status of doors, windows and ignition, etc. Or remotely monitor cutting off gas and power supply, etc.**
- **Sometimes, if users want to upgrade the AVL version, then we will give users new software firmware to update it. In this situation, please contact our service center.**

- In order to acquire more important details, you should pay much attention to some signs and supplementary information, such as:

【note】 : Means you must pay much attention, it includes many important details which you may overlook.

【caution】 : Warning information on relative topic, you should read it carefully, for fear causing unwanted loss.

【more information】 : More relative information about a certain topic, sometimes it is another easy way for the same purpose.

And if some words are marked in red color, that indicates the words should be paid much more attention.

Catalog

I. Welcome to use this car product.....	2
1.1 Introduction.....	5
1.1.1 Key Feature.....	6
1.2 Accessories.....	7
1.3 Specification.....	7
1.4 Outside feature.....	8
1.4.1 Socket and Switch.....	9
1.4.2 I/O ports.....	9
1.4.3 Connect Relay to control the Car Oil/Power. (port 5).....	12
1.4.4 Connect to the fuel sensor to detect the fuel.(port 4/6).....	13
II. Get started, please follow me!.....	14
2.1 Installation Guide.....	14
2.2 Send instructions and track a vehicle.....	18
2.3 View AVL trace on PC.....	20
2.3.1 Input position data to map software.....	20
2.4 GPRS Setting Step by Step.....	21
2.5 Common questions and solution.....	26
2.6 Listen-In function.....	28
2.7 send the GPRS interval time data on standby.....	28
III. Attachment.....	28
3.1 SMS instruction list.....	28
3.2 Update the firmware of the AVL.....	36
3.2.1 IAP Update User Guide.....	36

Thank you for using the car product, which is mainly for tracking the vehicle, anti-thief, and remotely monitoring the car through I/O ports socket of AVL, etc. All of these functions not only can be done by using a mobile phone, but also using Server via GPRS. According to the user's different need, our company has different version as below:

1.1 Introduction

Software Function	
Single location	✓
Tracking	✓
Over-speed alarm	✓
Geo-fence alarm	✓
Wake up alarm	✓
Sleep alarm	✓
SOS alarm	✓
GPRS Function	✓
Heartbeat function	✓
I/O ports trigger alarm	✓
Low battery alarm	✓
Exterior battery cut off alarm	✓
Physics Speciality	
Inner Lithium battery	✓
Charged by exterior DC	✓
Tremble Senor-based	✓
Anti-theft Alarm	✓
SOS button or Button A	✓
Switch input	✓ (2 ports)
Digital input	✓ (2 ports)
Digital output	✓ (2 ports)
Analog input	✓ (2 ports)

1.1.1 Key Feature

In the Basic Version, by using the AVL, user can track the vehicle via SMS or GPRS and monitor the status of the door, window, and engine of the car through I/O sockets. The more detailed function as below:

- **Internal Polymer Lithium Ion Battery in the AVL**
- **Can be charged by exterior DC 9 - 36 V**
- **Exterior battery cut off alarm**
- **Support mini USB port to update firmware**
- **Low power consumption**
- **Over-speed alarm**
- **Geo-fence alarm**
- **Low power alarm**
- **With SIMCOM GSM/GPRS module and Sirf-StarIV GPS chipset**
- **Support single location and continual tracking**
- **Can Real-time tracking your vehicle via map on PC**
- **GPRS function, receiving position data and alarm data on Server**
- **Anti-theft alarm, support alarm when someone tremble your car once you park it and send an alarm report to you via SMS or GPRS data**
- **Remotely detect the status of the Windows or Doors or Engine close/open through the Digital Input sockets.**
- **Remotely cut the Oil/Engine power through the Digital Output socket.**
- **SOS button send out exact location for immediate rescue. After user press SOS button in the AVL, AVL unit will send out the location and SOS alarm to the preset number via SMS or a Server via GPRS**
- **With 32M memory, this can store about 16000 PCS data. When GPRS is lose connection, those data will be store and send when GPRS connection is recover.**
- **Calculate the milemeter of the car from the GPRS data.**
- **Detect the car of the fuel.**
- **With Temperature sensor**
- **With Microphone and headset function.**

- Two-way conversation

1.2 Accessories

Thank you for your purchase of the AVL, after you get it, please checking all the accessories in the box:

	Accessories
GSM Antenna	✓
GPS Antenna	✓
Cables	✓
User Manual CD	✓
Below is Optional:	
Configure Cable (Optional)	✓
Car Charge (Optional)	✓


If there is any part damaged or absent, please contact your dealer as soon as possible, and if you have any questions or problems when using it, you can contact our service center.

1.3 Specification

Feature	Characteristics
Dimension	96mm*65mm*25mm
Exterior Power Supply	DC 9V -- 36V
Inner lithium battery	DC 3.6V -- 4.2V
Exterior GSM antenna	Receive GSM signal better
Exterior GPS antenna	Receive GPS signal better
Power Consumption when exterior voltage is 12V	Active mode(avg.) < 100mA Sleep mode < 5mA
Operating Temperature Range	-20°C to +60°C
Air pressure	860Kpa --1060Kpa

Humidity	Up to 75% non-condensing
Position accuracy	10 --15 meters
GSM chip	4 Frequency GSM 850/ 900/1800 /1900MHZ
GPS chip	Sirf-Star IV (super-sensitivity and high accuracy)
LED	3 LEDs indicates GSM, GPS signal, and trembling status
Button	2 buttons, SOS button,Button A(Can call the specified number)
I/O port	1 SOS button, 2 digital input(positivel input), 2 switch input(negative input), 2 digital output,2 analog input

1.4 Outside feature




1.4.1 Socket and Switch

Hardware	Function
A. Headset	Connect the microphone and headset
B. I/O Sockets	Expanding function, as below
A.Switch	Open/Close the unit
D.USB port	Support “USB Converter” to update firmware
E. GPS Antenna a socket	Connect Exterior GPS Antenna
F. GSM Antenna a socket	Connect Exterior GSM Antenna
G.Three LED	GSM LED(Left),Power & tremble Led, GPS Led
H. SIM Card Holder	Hold a SIM card

1.4.2 I/O ports

We currently have two kinds of AVL05 interface line, a line of the old interface, the other is a new interface cable.



2)GND	4)Analog Input 1 (ADB input)	6)Analog Input 2 (ADA input)	8) Reserve	10) GND	12)GND	14) GND	16)GND	18) GND	20)V+ (12V-24V)
-------	--	--	---------------	---------	--------	---------	---------	------------	--------------------


ISOS Button (With GND)	3)Button A (With GND)	5)Digital Output A (12V)	7)Digital Output B (12V)	9) Switch Input 1 (With GND)	11) Switch Input 2 (With GND)	13)Digital Input3 (12V)	15)Digital input4 (12V)	(17) Reset	(19) Reserve
--	---------------------------------	--	--	--	---	---	---	-----------------------------	-------------------------------

Notes: The sequence of the 13 sockets in the diagram are for the corresponding sockets in the above picture. Please do not confuse the direction, the Switch is the right side of I/O Sockets. The function is as below:


NO.	Function
I/O 01	When SOS Button cable is connected to GND(port 02), namely trigger, the unit will send out a data via SMS or GPRS, alarm type is “01”
I/O 02	GND, use for input GND
I/O 03	When this cable is connected to GND(port 02), Device will send a GPRS alarm data to Server. (Old Hardware version is Reset button)
I/O 04	AD input, Gather to the digital of voltage
I/O 05	Using a phone can set the voltage value of the digital output through “025” instruction, high or low, by virtue of it, user can remote Control the Car window or door close/open
I/O 06	AD input, Gather to the digital of voltage
I/O 07	The function is the same as I/O 05
I/O 09	When this cable is connected to GND(port 02), Device will send a GPRS alarm data to Server. And when connect is lose , Device also will send a GPRS alarm data to server, user can monitor car window status(According to the customer's own vehicle)
I/O 10	GND, use for input GND
I/O 11	When this cable is connected to GND(port 02), Device will send a GPRS alarm data to Server. And when connect is lose , Device also will send a GPRS alarm data to server,user can monitor car window status(According to the customer's own vehicle)
I/O 12	GND, use for input GND
I/O 13	The function is similar as I/O 09, but the triggered voltage must be high, alarm type is “54”, “55”, through it , user can monitor the status of ignition or Car window status *At present, most of customers use this cable to connect to the engine of car.
I/O 14	GND, use for input GND
I/O 15	The function is the same as I/O 13, but the alarm type is “56”, “57”
I/O 16	GND, use for input GND
I/O 17	When this cable is connected to GND(port 18), Device will be RESET (Old Hardware version without this cable)
I/O 18	GND, the voltage is ‘0’, The cathode of power input socket
I/O 20	The anode of power input socket

Note: The port that no mark is leave to customize.

Ports Graphics




1.4.3 Connect Relay to control the Car Oil/Power. (port 5)




1.4.4 Connect to the fuel sensor to detect the fuel.(port 4/6)

Our AVL can get the voltage by the AD collection and according to the voltage change to know the fuel level in the tank. because the fuel tank in different car is different .so you need to find out the different relation between the voltage and fuel .our AVL can collect the voltage from 0-18V.so that mean if you want to know the fuel leave in the fuel tank, so you should work out the coordinate relation between voltage and fuel in your server. when the GPRS data come to the server, the server work out fuel level in the tank by analyze the GPRS data.



Picture 1 (how to connection)



Picture 2 (About the fuel meter)

II. Get started, please follow me!

2.1 Installation Guide

♣ Step1: Inset a SIM card.

(1) Using a needle to press the yellow plastic (in the hole), then the cover of SIM card will pop-up, take the slipcover of SIM card out to put the SIM card in it, with the chip module up, as the below pictures shows:



(2) Put back the front cover, and move the sliding cover to the unit.

【note】 :Please make sure the SIM card can communicate with other cards via SMS and call, and before installing the SIM card to the holder, please use a mobile phone to empty the SMS storage of the card.

♣ **Step2: Connect GSM Antenna and GPS Antenna to AVL unit.**

(1) Fasten the connection by turning the metal end of the antenna, until the connection is very firm.

As the below picture shows, the above socket is for GSM antenna, the below is for antenna in picture 1, picture 2 is GPS antenna, picture 3 is GSM antenna.



Picture 1



Picture 2 (GPS Antenna)



Picture 3 (GSM Antenna)

【note】 : We would better to put the GPS antenna top to the open air out of the car to get more GPR signal, or make sure that it will not be covered or shielded by any electromagnetic object.

【more information】 :AVL relies on GSM and GSP system for location and communication, so we must make sure that GSM signal and GSP signal are in good state.

- GSM is the abbreviation of Global System for Mobile Communication. At first, you should insert a phone (SIM)card into the AVL, In virtue of GSM system, AVL and your mobile phone in hand can communicate with each other.
- GPRS is General Packet Radio Service, is a service technique based on GSM, by virtue of the service, the AVL can communicate with a Server.
- GPS is the abbreviation of Global Positioning System. There are 24 positioning satellites around the earth sending GPS signal to the AVL straightly. In order to receive signal, the top of GSP antenna cannot be shielded or covered by any electromagnetic object. The use can bring the top of GPS antenna to the open air for better GPS signal. If AVL is in a shielding environment temporary, please don't worry, because once the AVL leaves the shielding environment, it will regain GPS signal. Further, the product can provide accurate position

information under dynamic condition, the precision will be kept within 10 to 15 meters.

♣ **Step 3: Fix the AVL in your car and connect the AVL to the power of your car.**

(1) Connect the wires to the I/O socket, please make sure the wires has inserted to the I/O socket firmly. As below:



(2) look at the above pictures shows, Connect Pin20 to the anode of the Car Battery, and Pin18 to the GND of Car battery GND, please note that the exterior voltage must be between 9 V and 36V, please make sure to comply with it.

【more information】 : AVL unit have lithium battery in it, and if AVL is cut off from the power of the car, lithium battery will supply power to the AVL. Once AVL is connected to the car power, lithium battery will be charged until it reaches full.

【caution】 :After you have completed all the process, we must check that the wiring connections are firm and reliable, and the joints are wrapped with insulating tape tightly.

♣ **Step 4: Turn on the AVL, observe the three LEDs in the AVL.**

(1) Turn on the AVL, you will see the three LEDs flash at the same time.

It entered into initial mode.

(2) After about 25 S, the AVL will enter into work mode, Look at the picture, with various statuses as below.

● LED Indicators



LED1 (green color)	GSM Indicator
LED2 (orange color)	Tremble &Power sensor Indicator
LED3 (blue color)	GPS Indicator

LED	State	Meaning
Tremble sensor LED (orange LED)	light 0.1s dark 0.1s	System Initial
	light	Trembling
GSM LED (green LED)	light 0.1s dark 0.1s	System Initial
	light 0.1s dark 2.9s (flash)	GSM receiver work well
	light 1s dark 2s (glow periodically)	No GSM signal
GPS LED (blue LED)	light 0.1s dark 0.1s	System Initial
	light 0.1s dark 2.9s (flash)	GPS receiver work well
	light 1s dark 2s (glow periodically)	No GPS signal

When AVL is in work mode, if GSM signal is in good state, the green led will flash, similarly, if GPS signal is in good state, the blue led will flash, if the green led is not flashing, that indicates the GSM signal is not good, if the blue led is not flashing, then you should check if there is something upon the GPS antenna top. Further, if you find the three leds are dark, maybe the AVL entered into "sleep-mode" or there is no power in the AVL unit.

2.2 Send instructions and track a vehicle

♣ Ask for a present position of your vehicle

No matter where you are, when you want to know the position of your vehicle, make a telephone call to the AVL, it will report its location to you by SMS, or you can send a SMS to it.

Edit a message as following format, and send it to the AVL:

SMS Format: ***+Password+, +000#** (*init password is : 000000*)

For example: ***000000,000#**

The AVL will send a SMS back to you, including longitude &latitude data.

【note】 : * is the begin letter (you can use a W to instead of it, we support begin with * and W), 0 is a number zero, not a letter. And please do not enter spaces or

hyphens in the SMS. And the user must make sure that the AVL unit is not in "sleep" mode.

♣ Modify your password

Before you use the AVL, you should modify your password, for fear controlling the AVL by other people, you can use the "001" instruction.

SMS Format: ***+Password+, +001+, @@@@#@#**

For example: if you want modify your password to 123456, you can send **"*000000,001,123456#"** to the SIM card in the AVL. If you send it successfully, after a few seconds, it will send "Receive:'001'OK *000000,001,123456#" to you automatically. After this, your password will be 123456. Then when you do the next process, you should bear the password in mind.

【note】 : If you have changed your password, the password in SMS command isn't 000000 anymore, it must be the modified password, please note it.

♣ Track your vehicle

Tracking report function can be turned on or off according to the requirements of the user, by using "002" instruction, you can set a time interval (X), report times(Y). That is to say, you can receive position report at X mins interval, and report Y times before it stops.

SMS Format: ***+Password+, +002+, X,+Y #**

For example: ***000000,002,2,30#**

If the AVL received it successfully, it will send one SMS back to check it, then send you position message every 2 mins, 30 times.

【more information】 : X means Time interval (Unit: min)

It can be one of 0~999, X=0 means stop tracking;

Y can be one of 0~999, Y=999 means it will not stop tracking(until another stop instruction)


Y=0, Disable this function

2.3 View AVL trace on PC

2.3.1 Input position data to map software

1. Launch Internet Explorer on your computer. Other browsers may Also work, but Internet Explorer is recommended.
2. Download google-earth software from <http://earth.google.com/>
Type "<http://maps.google.com>" to connect to Google Map website for displaying the location map.
3. Put the longitude &latitude which you received from the SMS into the google earth map or <http://maps.google.com> .chick on search button, then you will find the position fixed. As the following picture shows.

【note】 :Please pay attention to change the position data format.



2.4 GPRS Setting Step by Step

This is a wonderful function, by virtue of GPRS, user can track the car, and view status of the car conveniently on PC. The GPRS ID of AVL, is use the IMEI number of GSM module. You can send sms command ***000000,801#** to AVL to check it.

【note】 : Please note that, in the bellow steps, **\$\$\$\$\$\$** is user password.

- Step1: Make sure that your SIM card in the AVL has GPRS function.
- Step2: Set APN

Every country has its APN, please refer to the attachment.

SMS format: ***\$\$\$\$\$,011,APN,Username>Password#**

For example: ***000000,011,cmnet,,#**

The user name and password can be null, “cmnet” is a Chinese’s APN.

After you send the SMS, it will send one SMS back to check it.

- Step3: Set IP Address & port number

By sending the SMS command, you can connect your AVL to Server by gprs.

SMS format: ***\$\$\$\$\$,015,0,IP,PORT#**

For example: ***000000,015,0,72.167.29.18,3308#**

72.167.29.18 is the server’s IP address, 3308 is the port..

If you want to send GPRS data to ours server test,ours server’s IP address is 66.160.134.223,port is 10085,but must let us activate IMEI, If client have the server by oneself, pls make sure the IP and port is correct.

- Step4 Set GPRS time interval

SMS format: ***\$\$\$\$\$,018,X,Y#**

X is the time interval, Y is the times of data has been sent.

For example: ***000000,018,300,999#**

This command is to set up the time interval is 5 mins and no times limit.

- Step5: Enable GPRS function

Send a SMS as following format.

SMS format: *\$\$\$\$\$,016,X#

For example: *000000,016,1#

X must be 1, meaning: Enabling GPRS function.

And, X is 0 means close GPRS function.

● **Step6: Receive alarm type information on Server**

The data received format in the Server is as below:

The GPRS command server sent to device must be 8-bit ASCII format. The GPRS command must be same as sms command in this user guide.

The data of the device send to the server:

Format: \$\$ (2 Bytes) + Len (2 Bytes) + IMEI (15 Bytes) + | + AlarmType (2 Bytes) + GPRMC + | + PDOP + | + HDOP + | + VDOP + | + Status (12 Bytes) + | + RTC (14 Bytes) + | + Voltage (8 Bytes) + | + ADC (8 Bytes) + | + LACCI (8 Bytes) + | + Temperature (4 Bytes) + | + Mile-meter (14 Bytes) + | + Serial (4 Bytes) + | + Checksum (4 Byte) + \r\n (2 Bytes)

The format of ASCII:

\$\$B0353358019462410|AA\$GPRMC,102156.000,A,2232.4690,N,11403.6847,E,0.00,,180909,,*15|02.0|01.2|01.6|000000001010|20090918102156|14181353|00000000|279311AA|0000|0.7614|0080|D2B5

Code	Explanation
\$\$	2Bytes, indicates header of command from tracker unit to call centre, in ASCII code (hex is 0x24).
Len	2Bytes, indicates length of all command, including header and end (the array is first high to low).
IMEI	15Bytes, at most 20 bytes.
Alarm type	2Bytes, the GPRS data trigger type.
DATA	GPRMC string
	PDOP
	HDOP
	VDOP
	Status (12bytes)
	RTC (14bytes)

	Voltage(8bytes)
ADC	8bytes,the ADC value.
LACCI	Location information elements
Temperature	Temperature information
Milemeter	Mileage data
Serial ID	4bytes, sign every GPRS data, the range is [0001-9999], then circle it again from 0001 to 9999.
Checksum	<p>4Bytes, means CRC check of all the data ahead, CRC-16 modbus (Polynomial = 0xA001, initialize data is 0xffff) checksum, not including its own byte and end characters. For example:</p> <p>\$\$B0353358019462410 AA\$GPRMC,102156.000,A,2232.4690,N,11403.6847,E,0.00,,180909,,*15 02.0 01.2 01.6 000000001010 20090918102156 14181353 00000000 279311AA 0000 0.7614 0080 D2B5</p> <p>D2B5= CRC-16 modbus</p> <p>(\$\$B0353358019462410 AA\$GPRMC,102156.000,A,2232.4690,N,11403.6847,E,0.00,,180909,,*15 02.0 01.2 01.6 000000001010 20090918102156 14181353 00000000 279311AA 0000 0.7614 0080).</p>
\r\n	2Bytes, end char (hex format is 0x0d,0x0a).

- Alarm type
 - 0x01 SOS button is pressed
 - 0x49 Button A is pressed
 - 0x09 Auto Shutdown Alarm
 - 0x10 Low battery Alarm
 - 0x11 Over Speed Alarm
 - 0x13 Recover From Over Speed
 - 0x14 Deceleration Alarm
 - 0x15 Acceleration Alarm
 - 0x30 Parking Alarm
 - 0x42 Out Geo-fence Alarm
 - 0x43 Into Geo-fence Alarm
 - 0x50 IO-1 Close —Switch input 1 closed PORT9
 - 0x51 IO-1 Open —Switch input 1 opened PORT9
 - 0x52 IO-2 Close —Switch input 2 closed PORT11
 - 0x53 IO-2 Open —Switch input 2 opened PORT11
 - 0x54 IO-3 Close —digital input 3 closed PORT13
 - 0x55 IO-3 Open —digital input 3 opened PORT13
 - 0x56 IO-4 Close —digital input 4 closed PORT15
 - 0x57 IO-4 Open —digital input 4 opened PORT15

- 0x60 Begin Charge
 - 0x61 End Charge
 - 0x77 Angle Alarm
 - 0x88 Heartbeat
 - 0x91 Into Sleep Mode
 - 0x92 Wakeup From Sleep Mode
 - 0xAA Interval GPRS data
- Status(12 Bytes) — Status:
 - Byte 01 — SOS button
 - Byte 02 — Button A button
 - Byte 03 — Switch Input 1 PORT9(According to different cars, can detect the door state, Negative input 1)
 - Byte 04 — Switch Input 2 PORT11(According to different cars, can detect the door state, Negative input 1)
 - Byte 05 — Digital Input 3 PORT13 (some times connect to the engine, Positive Input 3)
 - Byte 06 — Digital Input 4 PORT15 (some times connect to the door, Positive Input 4)
 - Byte 07 — Digital Input 1
 - Byte 08 — Digital Input 2
 - Byte 09 — Digital output A PORT5
 - Byte 10 — Digital output B PORT7
 - Byte 11 — Reserve
 - Byte 12 — Out 4 (reserve)
- Voltage(8 Bytes) — Value of the voltage:
 - Format: ABBBBIII
 - A — Charge Status (0 = Off Charge , 1 = On Charge)
 - BBB — Battery Voltage (For example, 367 mean 3.67V)
 - III — Input Charge Voltage (For example, 1251 mean 12.51V)
- ADC(8 Bytes) — AD collection:
 - Format: CCCCDDDD
 - CCCC — ADA collect (For example, 1251 mean 12.51V)
 - DDDD — ADB collect (For example, 1251 mean 12.51V)
- LACCI(8 Bytes) — Location information elements:
 - Format: LLLLCCCC
 - LLLL — Location area code
 - CCCC — Cell ID
- Temperature(4 Bytes) — Temperature (reserve for the device has no temperature sensor):
 - Format: STTT
 - Precision is 0.1℃
 - The first byte “S” mean sign, such as “0/1/-”
 - Eg: 0345 mean +34.5℃, 1234 mean +123.4℃, -123 mean -12.3℃
- Mile-meter(14 Bytes) — Location information elements:

- Format is AAAA.BBBBKm.
- Four bytes after the radix point.
- Serial(4 Bytes) —— Serial number:
 - Format: SSSS
 - Every time reboot the device or reset,the serial number will initialize to 0001.
 - Every GPRS message send out will add one
 - After the serial number to 9999, restart from 0001 again

This is the AVL05 GPRS data short format communication protocol.

Code	Explanation
\$\$	2Bytes, indicates header of command from tracker unit to call centre, in ASCII code (hex is 0x24).
IMEI	5Bytes
Alarm type	2Bytes, the GPRS data trigger type.
GPRMC	Positioning logo
	Alarm type
	speed
	Direction
\r\n	2Bytes, end char (hex format is 0x0d,0x0a).

Format: \$\$ (2 Bytes) + IMEI (5 Bytes) + Alarm Type (2 Bytes) + GPRMC (33 Bytes) + \r\n (2 Bytes)

\$\$07311AAA2232.3502N11403.8126E0.00*95.13

- Alarm type
 - 0x01 SOS button is pressed
 - 0x49 Button A is pressed
 - 0x09 Auto Shutdown Alarm
 - 0x10 Low battery Alarm
 - 0x11 Over Speed Alarm
 - 0x13 Recover From Over Speed
 - 0x14 Forward acceleration alarm
 - 0x15 Reverse acceleration alarm
 - 0x30 Parking Alarm
 - 0x42 Out Geo-fence Alarm
 - 0x43 Into Geo-fence Alarm
 - 0x50 IO-1 Close
 - 0x51 IO-1 Open
 - 0x52 IO-2 Close

- 0x53 IO-2 Open
- 0x54 IO-3 Close
- 0x55 IO-3 Open
- 0x56 IO-4 Close
- 0x57 IO-4 Open
- 0x60 Begin Charge
- 0x61 End Charge
- 0x77 Angle Alarm
- 0x88 Heartbeat
- 0x91 Into Sleep Mode
- 0x92 Wakeup From Sleep Mode
- 0xAA Interval GPRS data

The link of the explain about the CRC-16(modbus):

<http://www.lammertbies.nl/comm/info/crc-calculation.html>

2.5 Common questions and solution

While you are operate your AVL, if you detect any question, please check if the following paragraph can help you.

■ **Q: You sent one SMS to the AVL, then if you receive one SMS, reading "Set error....."in a few mins. What happened?**

■ **A: your SMS command must have a format error, please check it:**

(1): Has your password been modified? And is the password right?

(2): W must be capital letter, and, if your password is initial, then, 0 is a number, not a letter.

(3): There is no space in the SMS, and you must check the symbol in the SMS.

■ **Q: When I call the AVL for a position, why is the AVL busy now?**

■ **A: (1) please check if GSM signal is in good state, Check if the green led is flashing. If the green led is growing periodically, not flash. That indicates the GSM signal is not in good state, you should wait for a minutes or remove it to anther position. If the green led is dark, the AVL must be in "sleep mode",**

please note (2).

(2) If you find the there leds are dark at the same time, the AVL is in "sleep mode", you must wake it up, or you can turn off the "sleep mode" function. You can use "021"SMS command, please refer to the SMS instruction list. You can send:" *\$\$\$\$\$,021,00#"to the AVL(***** is your password).

If the AVL send a suScsessful SMS back, it indicates the AVL will never enter into sleep (until you change it).

(Unfinished, will be added!)

2.6 Listen-In function

If you need to use the listen-in function, please send ***000000,008,0010000#** to device, so that you can use the cell phone call in and device will auto into the listen in mode.

If you want to disable the listen-in function, please send ***000000,008,1000000#** to device.

2.7 send the GPRS interval time data on standby

Detected according to the GPS speed is less than 5 km/h or judgment vibration sensor for the stationary state, the machine will enter standby state, the machine will send GPRS data according to the set time.

If you want to enable this function , you can set 023 command .

***000000,023,X,Y#**

III. Attachment

3.1 SMS instruction list.

If you want to know more about the AVL, and design your special AVL, you can refer to the SMS instruction list.

\$\$\$\$\$ is user`s password , and initial password is **000000**

	SMS Instruction	Format	Note
1	Modify user password	*\$\$\$\$\$,001,@ @ @ @ @ #	\$\$\$\$\$ is old password @ @ @ @ @ is new Password

2	<p>Set the time intervals of position notice SMS</p> <p>The Position SMS will send to the preset SOS number.</p>	*\$\$\$\$\$,002,X,Y#	<p>X (Max 3 Digital) =0, Stop send position SMS =[1,60000] Time interval (Unit: mins)</p> <p>Y (Max 3 Digital) =[1,999) times send SMS Y=0, Disable this function Y=999, continue send SMS</p>
3	<p>Set a preset phone & SMS number for SOS button</p>	*\$\$\$\$\$,003,O,F,CallNumber, SMS Number#	<p>F = 0, Disable this function =1, Only send an alarm SMS to the preset SMS Number Notice :Tel Number and SMS Number (must <25 digits)</p>
4	<p>Set low power alarm</p> <p>When the AVL voltage is lower than the preset value, AVL will send one lower power alarm GPRS data to the Preset Server.</p>	*\$\$\$\$\$,004,XXX,YYY#	<p>XXX is the low power alarm voltage, eg: 3.8v, XXX=380 YYY is the auto shut down voltage, eg: 3.5v, YYY=350 For example: *\$\$\$\$\$,004,380,350#</p>
5	<p>Set over speed alarm</p> <p>When the AVL speed higher than the preset value, AVL will send one over speed alarm GPRS data to the Preset Server.</p>	*\$\$\$\$\$,005,S,X,Y,Z#	<p>S=1 Enable speed alarm, S=0 Disable speed alarm. X=[10<XXX<250] (The speed preset value) unit is km/h Y is the times over speed [10,999] unit is second Z=[10,360],(The time interval to send speed alarm) unit is second.</p>
6	<p>Set Geo-fence alarm</p> <p>When the AVL move out preset scope, AVL will send one Geo-fence GPRS data to the Preset Server.</p>	*\$\$\$\$\$,006,+lat1,+long1,+lat2,+long2,X,Y#	<p>Lat=[-9000.0000,+9000.0000] Long=[-18000.0000,+18000.0000] X=[10,360] is for time interval send alarm message. Y=0, Disable GEO-fence alarm. Y=1, Into GEO-fence alarm. Y=2, Out of GEO-fence alarm. Note: Long1>long2&lat1>lat2 Make sure the position of north latitude and east longitude set it (+), otherwise set it (-)</p>

			<p>Format:+AAAAA.BBBB</p> <p>Make sure set the two position have the same digit after comma.</p>
7	Extend setting	*\$\$\$\$\$\$,008,ABCDEFG#	<p>A=0, Disable position report function which get position SMS by Calling</p> <p>A=1, Enable position report function which get position SMS by Calling</p> <p>B=0, Send the SMS in Text format.</p> <p>B=1, Send the SMS in NMEA format.</p> <p>C=0, AVL hung up after 4~5 rings when call incoming</p> <p>C=1, AVL do NOT hung up when one call incoming</p> <p>D=0 Machine normally send all SMS</p> <p>D=1 machine only receive text messages don't send any SMS</p> <p>E=0, ADB Normal AD collect</p> <p>E=1, ADB Oil collect.(The average of two minutes to collect)</p> <p>F=0, ADA Normal AD collect</p> <p>F=1, ADA Oil collect.(The average of two minutes to collect)</p> <p>G=0</p>
8	Change buad	*\$\$\$\$\$\$,009,S#	<p>S=0, work in 900/1800</p> <p>S=1, work in 850/1900</p> <p>S=2, Automatic selection</p> <p>S=3, not set(default)</p> <p><i>*note: the default of parameter is S=3, not set the frequency band, if the unit of GSM module support three frequency(900/1800/1900), then you could set the parameter to S=0, if the unit of GSM module support the four</i></p>

			frequency(850/900/1800/1900),then you could set the parameter to S=1.
9	Set APN,Username,Password	*\$,\$,\$,\$,\$,\$,011,APN,Username,Password#	APN : APN string (must < 28 chars) User name: Your username (must < 28 chars) Password: Your password (must < 28 chars) * If haven't username or password, then left it blank. For example: *000000,011,CMNET,,## (It haven't username and password)
10	Set DNS	*\$,\$,\$,\$,\$,\$,014, X,DNS1,DNS2# Disable the DNS	X=0 Disable the DN X=1 Enable the DNS DNS is the domain name server , xxx.xxx.xxx.xxx
11	Set IP Address Or Domain & port number	*\$,\$,\$,\$,\$,\$,015,X,IP/DN,PORT#	X=0 use IP connect the server X=1 use DN connect the server IP : xxx.xxx.xxx.xxx DN:(domain name) www.xxx.com PORT : [1,65535]
12	Set the time intervals of GPRS Data	*\$,\$,\$,\$,\$,\$,018,X,Y#	X (3 Digital) =0 stop send time interval GPRS =[10,999] Time interval (Unit: sec) Y (3 Digital) =0, stop send time interval GPRS = [1,999] After send YYY times stop. =999, continue send GPRS un-stop
13	Enable/Disable GPRS function	*\$,\$,\$,\$,\$,\$,016,X#	X=0 Disable GPRS Function X=1 Enable GPRS Function This is the last step of GPRS setting.
14	Set the GPRS mode	*\$,\$,\$,\$,\$,\$,019,X#	X=0, Use the UDP mode X=1, Use the TCP mode

15	Tremble sensor switch	*\$,\$,\$,\$,\$,021,XY#	X = 0 Disable Sleep mode X = 1 Enable Sleep mode Y = 0 Disable the tremble sensor Y = 1 Enable the tremble sensor
16	Set the Module	*\$,\$,\$,\$,\$,022,X,Y#	X=0, Close the GPS module when into sleep X=1, Open the GPS module when into sleep. Y=0, Close the GSM module when into sleep Y=1, Open the GSM module when into sleep
17	Enable/Disable I/O port	*\$,\$,\$,\$,\$,025,X,Y#	X=A, port 5 X=B, port 7 Y=0, Out port is high (the circuit will restore) Y=1, Out port is low (the circuit will be cut off) eg: *000000,025,A,1# Circuit to port 5 will be cut off
18	Heart Beat Switch	*\$,\$,\$,\$,\$,040,X#	X=0 Disable the heart beat function X=1 Enable the heart beat function
19	Heart Beat Intervals	*\$,\$,\$,\$,\$,041,X#	X is the heart beat interval, unit is minute [1<X<9999] X=0, Disable this function.
20	Into sleep mode when without tremble for preset time	*\$,\$,\$,\$,\$,044,X#	After the tremble sensor don't tremble for X second, tracker will into sleep mode 30< X <65536 (Unit : second) For Example, configure AVL05 into sleep mode after no tremble for 30 second: *000000,044,30#
21	Wake up from Tremble	*\$,\$,\$,\$,\$,043,X#	After the tremble sensor continuous tremble for X second, tracker will wake up X=[1,255) (Unit : second) AVL05 Wake up from sleep mode after no tremble for 10 second:

			*000000,043,10#
22	Set Oil sensor	*\$\$\$\$\$\$,113,A,B#	<p>A,B=[0,2000], the real voltage is [0,20V].</p> <p>A is the empty fuel of corresponding voltage, B is the full fuel of corresponding voltage.</p> <p>*note: Every different types of car have different corresponding relation.</p> <p>Pls test it by yourself ,then set the command.</p> <p>Eg: *000000,113,100,500#</p> <p>Explain: it means empty fuel of corresponding voltage is 1V,and the he full fuel of corresponding voltage is 5V,if the AVL detect the voltage is 4V,then the value of fuel percent is $(4-1)/(5-1)=75\%$.</p>
23	Set OutA Change	*\$\$\$\$\$\$,117,A,B,C,D#	<p>A=[0,999]km/h , the thresold of speed.</p> <p>B=[0,60000] ms,, the interval of outA off</p> <p>C=[0,60000] ms,, the interval of OutA on</p> <p>D=[0,99], the times of OutA change</p> <p>If the speed is lower than, the OutA will off B seconds, then restore C seconds, repeat it D times.</p> <p>*note : because of the safety, you had better set the parameter like this: *000000,117,60,500,3000,5#</p>
24	OutA Change switch	*\$\$\$\$\$\$,116,A#	<p>A=1, active 117 command set .</p> <p>A=0, Don't active 117 command set</p>
25	Set Call A	*\$\$\$\$\$\$,103,S,Number#	<p>This command set the function for Button A.</p> <p>S=0, If the button trigger, send out one GPRS.</p> <p>S=1,If the button trigger, it will</p>

			<p>call the number.</p> <p>For example:</p> <p>*000000,103,0,1234#, press button A, it send out GPRS (alarm type 49)</p> <p>*000000,103,1,1234#, press button A, it will call the 1234#.</p>
26	Extend Setting	*\$\$\$\$\$\$,118,ABCDEFGH#	<p>A=0, Disable send the interval GPRS data normally when trembles (Default)</p> <p>A=1, Enable send the interval GPRS data normally when trembles</p> <p>B=0, Disable send the interval GPRS data normally when Input 4(Port 15) close(Default)</p> <p>B=1, Enable send the interval GPRS data normally when Input 4 (Port 15) close</p> <p>C=0, Disable send the interval GPRS data normally when Input 3(Port 13) close(Default)</p> <p>C=1, Enable send the interval GPRS data normally when Input 3 (Port 13) close</p> <p>D=E=F=G=0, reserved</p> <p>H=0, Long GPRS</p> <p>H=1, Short GPRS</p>
27	Set PIN	*\$\$\$\$\$\$,122,S,PIN#	<p>S=1, Active this function.</p> <p>S=0, Disable this function</p> <p>PIN is the pin code of the SIM card,</p> <p>If the pin code is not correct, the SIM card will be locked, device can't work normal.</p>
28	Reboot time	*\$\$\$\$\$\$,600,X,Y#	<p>X=0,Disable this function (Default)</p> <p>X=1, Active this function.</p> <p>Y= [10,9999]/ Minutes, Reboot time interval</p>
29	Angle Alarm	*\$\$\$\$\$\$,400,X,Y#	<p>X=0, Disable this function (Default)</p> <p>X=1, Active this function.</p> <p>X=2, Input 4 (Port 15)</p>

			is high-frequency alarm when the open angle X=3, Input 3 (Port 13) is high-frequency alarm when the open angle Y= [1,360] Angle range
30	Clear data flash	*\$\$\$\$\$\$,500#	Clear stored in the flash memory inside the machine
31	GPRS data transmission in the form	*\$\$\$\$\$\$,119,X#	X=0 GPRS transmission (Default) Y=1 SMS transmission
32	Acceleration and deceleration alarm	*\$\$\$\$\$\$,120,A,B,C#	A=0 Disable this function (Default) A=1 Active this function. B= [0,2000] Acceleration 0.1m/S'2 B= [0,2000] deceleration 0.1m/S'2
33	Roaming sending GPRS data interval time	*\$\$\$\$\$\$,121,X,Y,Z#	X=0 Disable this function (Default) X=1 Active this function. Y=[0,999] Roaming time interval (Unit: sec) Z , Network ID If the machine in roaming, in accordance with Y send data, if the machine is not roaming, according to the instruction to send data
34	ACK function	*\$\$\$\$\$\$,123,X#	X=0, Disable ACK function(Default) X=1, enable ACK function
35	Call filtering	*\$\$\$\$\$\$,130,X,Y#	X = 0 (default), disable this feature X = 1, turn on this feature. Y, caller location information to allow the telephone number of replies
36	data flash switch	*\$\$\$\$\$\$,601,X#	X=0,Disable data flash function X=1,enable data flash function (Default)
37	According to the digital input3 state decided to time intervals of	*\$\$\$\$\$\$,156,X,Y,Z#	X=0, Disable data flash function(Default)


	GPRS Data		X=1, Enable data flash function Y=[5,300]/seconds,Input3 detection to high level (engine ON) time interval Z=[5,3600]/seconds,input3 no detection to high level (engine off) time interval
38	Mileage send GPRS data	*\$,\$,\$,\$,\$,\$,151,X,Y#	X=0 Disable this function (Default) X=1 Active this function. Y=[0,60000]/M ,Mileage range
39	Set the ID instead of IMEI	*\$,\$,\$,\$,\$,\$,155,X,Y#	X=0 Disable this function (Default) X=1 Active this function. Y , ID number, [0 -15]
40	Idling alarm	*\$,\$,\$,\$,\$,\$,404,X,Y#	X=0 Disable this function (Default) X=1 Active this function.(digital input 3 on) Y=[0,200]/sec, Alarm data interval time
41	According to the speed of the GPS or vibration sensors send data interval judgment on standby	*\$,\$,\$,\$,\$,\$,023,X,Y#	X=0 Disable this function (Default) X=1 Active this function. Y=[0-1440]/min send time interval GPRS on standby

3.2 Update the firmware of the AVL


3.2.1 IAP Update User Guide

1) Install RS232 cable driver

A. At the first, Install the Driver for “USB Converter”




B. Connect the AVL unit to PC through RS232 cable, View the com port that the cable used



2) Turn on AVL device


3) Build a New Hyper terminal connect, fill the name, example as IAP_DL




4) Choose the Com Port that the RS232 Cable used



Choose all the option same as picture show below (All setting must the same as the picture)




5) Into Configure Mode




6) Turn Off AVL device

7) Press the SOS button and Turn on Power at the same time, Device all indicator will keep light at same time, Hyper terminal will display the interface like the picture follow(Come into IAP_V7 or Come into IAP, and then display CCCCC). Then choose Send file (Send-> Send File) at soon as possible, because the update mode will keep for 97 seconds, if out of this time update will not be process succeed.



Choose the firmware that you want to Update;
Protocol Choose: Xmodem



Press Send button, Will display a New Windows that show the update process.

The screenshot shows the 'Xmodem file send for IAP_DL' dialog box. The 'Sending:' field contains the file path 'F:\AVL03 20080519\TYGPSV401.2e.Bin'. The 'Packet:' field is set to '35' and 'Error checking:' is set to 'CRC'. Both 'Retries:' and 'Total retries:' are set to '0'. The 'Last error:' field is empty. The 'File:' field shows a progress bar with two bars and the text '4K of 63K'. The 'Elapsed:' field shows '00:00:02', 'Remaining:' is empty, and 'Throughput:' is empty. At the bottom right, there are 'Cancel' and 'cps/bps' buttons.

(6) When finish Update, Tracker will reboot automatically, and the GSM/GPS/Sensors light will blink quickly. After about 3-5 mins, this interface will shut by itself. **When the update is pressing, all indicator will off for 10 seconds, doesn't turn off power of AVL03, otherwise will cause MCU broken.**

The screenshot shows the 'Xmodem file send for IAP_DL' dialog box at a later stage. The 'Sending:' field remains the same. 'Packet:' is now '499'. The 'File:' field shows a progress bar that is nearly full and the text '63K of 63K'. The 'Elapsed:' field shows '00:00:47', 'Remaining:' shows '00:00:00', and 'Throughput:' shows '1355 cps'. The 'Cancel' and 'cps/bps' buttons are still present at the bottom right.

(7) When the AVL05 LED is blinking back to normal mode. **Make sure about 2 mins later, then turn Off and Turn On AVL05 again.(at this times the firmware will load the parameter to the unit).** Then the firmware updates finished.

3.3 Worldwide APN (Access Point Name) List

Country	Mobile operator	Access point name
Argentina	Personal	gprs.personal.com
Argentina	Unifon	internet.gprs.unifon.com.ar
Australia	Telstra	telstra.internet
Australia	Optus	internet
Australia	Three	3netaccess
Australia	Vodafone	internet
Austria	Max Online	gprsinternet
Austria	One	wap.one.at
Belgium	Orange	orangeinternet
Belgium	Mobistar	web.pro.be
Belgium	Proximus	internet.proximus.be
Bermuda	AT&T	proxy
Bermuda	Mobility	net.bm
Brazil	Claro	claro.com.br
Brazil	Oi	gprs.oi.com.br
Brazil	TIM	tim.br
Bulgaria	Mobitel (Mtel)	inet-gprs.mtel.bg
Canada	Fido	internet.fido.ca
Canada	Rogers AT&T	internet.com
Chile	Entel PCS	imovil.entelpcs.cl bam.entelpcs.cl
Chile	Telefonica GSM	web.tmovil.cl
China	China Mobile	cmnet
Croatia	VIPNET	gprs.vipnet.hr
Czech Republic	Eurotel	internet
Czech Republic	Oskar	internet
Czech Republic	Oskar prepaid cards	ointernet
Czech Republic	T-Mobile	internet.t-mobile.cz

Denmark	TDCmobil	internet
Denmark	Orange	web.orange.dk
Egypt	Vodafone	internet.vodafone.net
Dominican Republic	Orange Dominicana	orangenet.com.do
Finland	Telia Mobile	internet
Finland	DNA	internet
Finland	Sonera	internet
Finland	Radiolinja	internet
Finland	Saunalahti	saunalahti
France	Orange	orange.fr
France	SFR	websfr
France	Bouygues Telecom	eBouygTel.com
Germany	D2 Vodafone	web.vodafone.de
Germany	E-Plus	internet.eplus.de
Germany	O2	internet
Germany	Quam	quam.de
Germany	T-Mobile D1	internet.t-d1.de
Greece	Vodafone	internet.vodafone.gr
Greece	Telestet	gint.b-online.gr
Greece	Cosmote	internet
Hungary	Vodafone (Prepaid "Optimized")	vitamax.internet.vodafone.net
Hungary	Vodafone (Prepaid "Standard")	vitamax.snet.vodafone.net
Hungary	Vodafone (Postpaid "Optimized")	internet.vodafone.net
Hungary	Vodafone (Postpaid "Standard")	standardnet.vodafone.net
Hong Kong	CSL	internet
Hong Kong	Orange	web.orangehk.com
Hong Kong	New World	internet
Hong Kong	People	internet
Hong Kong	SmarTone	internet

Hong Kong	Sunday	internet
India	Orange, Hutch	www
Iceland	Siminn	gprs.simi.is
India	BPL Mobile	bplgprs.com
India	Airtel	airtelgprs.com
Indonesia	Telkomsel	internet
Ireland	O2	internet
Ireland	Vodafone	live.vodafone.com
Israel	Cellcom	internetg
Israel	Orange	internet
Italy	TIM	uni.tim.it ibox.tim.it
Italy	Vodafone Omnitel	web.omnitel.it
Italy	Wind	internet.wind
Latvia	Latvia Mobile Telefone	internet.lmt.lv
Luxembourg	LUXGSM	web.pt.lu
Luxembourg	Tango	internet
Malaysia	Celcom	celcom.net.my
Mexico	Movistar	internet.movistar.mx
Mexico	Telcel	internet.itelcel.com
Montenegro	Monet	gprs.monetcg.com
Netherlands	T-Mobile	internet
Netherlands	KPM Mobile	internet
Netherlands	Orange	internet
Netherlands	O2	internet
Netherlands	Vodafone (normal)	web.vodafone.nl
Netherlands	Vodafone (business)	office.vodafone.nl
New Zealand	Vodafone NZ	www.vodafone.net.nz
Norway	Netcom	internet.netcom.no

Norway	Telenor	internet
Pakistan	UFone	ufone.internet
Paraguay	Personal	internet
Paraguay	Tigo	internet.tigo.py
Philippines	Smart	internet
Philippines	Globe	internet.globe.com.ph
Poland	Era	erainternet
Poland	Idea	www.idea.pl
Poland	PlusGSM	www.plusgsm.pl
Portugal	Optimus	internet
Portugal	TMN	internet
Portugal	Vodafone (Telcel)	internet.vodafone.pt
Romania	Connex	internet.connex.ro
Romania	Orange	internet
Russia	BeeLine	internet.beeline.ru
Russia	Megafon	internet.nw
Russia	MTS	internet.mts.ru
Russia	PrimTel	internet.printel.ru
Saudi Arabia	Saudi Telecom	Jawalnet.com.sa
Serbia-Montenegro	Mobtel Srbija	internet
Serbia-Montenegro	Telekom Srbija	gprsinternet
Singapore	M1	sunsurf
Singapore	Singtel	internet
Singapore	Starhub	shwapint
Slovakia	Eurotel	internet
Slovakia	Orange	internet
South Africa	MTN	internet
Spain	Amena	amenawap

Spain	Telefonica (Movistar)	movistar.es
Spain	Vodafone	airtelnet
Sweden	Telia	online.telia.se
Sweden	Vodafone SE	internet.vodafone.net
Switzerland	Swisscom	gprs.swisscom.ch
Switzerland	Orange CH	internet
Switzerland	sunrise	internet
Switzerland	UMC	www.umc.ua
Taiwan	Chunghwa Telecom	internet
Taiwan	Far EasTone	fetnet01
Taiwan	KG Telecom	internet
Taiwan	Taiwan Cellular	internet
Thailand	AIS	internet
Thailand	DTAC	www.dtac.co.th
Turkey	Avea	internet
Turkey	Aycell	aycell
Turkey	Telsim	telsim
Turkey	Turkcell	internet
UK	Jersey Telecom	pepper
UK	O2	mobile.o2.co.uk
UK	T-Mobile	general.t-mobile.co.uk
UK	Vodafone UK	internet
UK	Orange	orangeinternet
Ukraine	Kyivstar GSM	www.kyivstar.net
Ukraine	UMC	www.umc.ua
USA	T-Mobile	internet2.voicestream.com
USA	AT&T	proxy
USA	Cingular	isp.cingular
Venezuela	Digital TIM	gprsweb.digitel.ve